

## Elite harness plug (located in left rear roof rail)

Orientation of this plug is dictated by a pin which is further from other outside perimeter pins. This is the ground pin and is located at 12 o'clock in this schematic.

